

INSTRUCTION MANUAL

Wi-Fi Link



この度は G FORCE 社製品をご購入いただき誠にありがとうございます。この説明書を最後までお読みいただき正しい手順でお使いください。本製品はスマートホンやタブレットからESCのセッティングを行うための製品です。専用アプリをインストールすることで、グラフィカルな画面でセッティングが行えます。

対応製品

- TS160 ブラシレスESC
 - TS120 ブラシレスESC (ブラックアルミエディション含む)
 - TS90 ブラシレスESC
 - TS120 ブラシレスESC
- ※別売りのPROGBOXを使用し、ESCのファームウェアを最新のVer2.01にアップデートしていただく必要があります。

製品仕様

- 入力電圧: 5-17V
- 入力電流: 200mA
- 動作温度: 0-50°C / 32-122°F
- 保管温度: -10-80°C / 14-176°F
- サイズ: 60.4x30x11mm
- 重量: 12g

専用アプリの設定

1. 専用アプリの「Gforce Link」をダウンロードします。
検索名: Gforce Link (iOS、アンドロイドとも共通)
※右下のQRコードをスキャンし、DLページにアクセスすることができます。
2. ESCとWi-Fi Linkを接続します。
※接続ケーブルは茶色/-、赤/+、橙/S



スマートホン



QRコードをスキャンして
専用アプリをダウンロード



3. ESCの電源を入れると、Wi-Fi LINKの電源ランプが点灯します。そのまま待つとWi-Fiインジケータが点滅を始め、電波を発します。

Wi-Fi Linkとスマートホンを接続する(iOSの場合)

1. 「設定」→「Wi-Fi」の順でタップし「GFORCE〇〇〇」と表示された項目を選択します。
2. パスワードの入力画面が表示されます。初期設定では「12341234」となっています。
3. パスワードを入力するとスマートホンとの接続が完了します。Gforce Link アプリを起動させると10秒ほどの読み込み時間の後に、セッティングが可能となります。
4. Gforce Link アプリで設定した内容は、画面上の「適用」をタップすることでESCに書き込まれます。

Wi-Fi Linkとスマートホンを接続する(Androidの場合)

1. 「設定」→「Wi-Fi」の順でタップし「GFORCE〇〇〇」と表示された項目を選択します。
2. パスワードの入力画面が表示されます。初期設定では「12341234」となっています。
3. パスワードを入力するとスマートホンとの接続が完了します。Gforce Link アプリを起動させると10秒ほどの読み込み時間の後に、セッティングが可能となります。
4. Gforce Link アプリで設定した内容は、画面上の「適用」をタップすることでESCに書き込まれます。

SSID、パスワードの変更

1. Gforce Link アプリ画面の左下にある「アップグレード」をタップし「AP」をタップします。
「SSID/Name」「Password」をそれぞれタップすると、任意の名称/パスワードを設定できます。
2. 任意の名称/パスワードを入力後、「Setting」をタップすると変更が適用されます。

Wi-Fi Linkの初期化

電源ランプ、Wi-Fiインジケータがともに点灯している状態でRESTOREボタンを5秒以上押し続けます。その後ESCの電源を入れなおすことで、Wi-Fi Linkの設定が初期化されます。

Ver 1.00

お問い合わせ先

製品カスタマーサポート: 03-6206-0059
電話受付: 月曜日～金曜日 (祝日・夏期休暇・年末年始を除く)
受付時間: 10:30～12:00, 13:30～16:30
(弊社での修理・調整は行っておりません。予めご了承ください)
<随時FAQをWebで更新しています。是非ご参照ください>
www.gforce-hobby.jp



G FORCE www.gforce-hobby.jp

輸入販売元: 株式会社ジーフォース 〒101-0044 東京都千代田区鍛冶町1-3-1 マシ神田ビル9階

当社に無断で複写・転写・転載を禁じます Copyright © 2014 G FORCE, Inc. All Rights Reserved

INSTRUCTION MANUAL

Wi-Fi Link



Thank you for purchasing Gforce Wi-Fi Link (G0034). Gforce Wi-Fi Link is a device connected to the speed controller so that you can modify setting of your speed controller via smart phone. This Wi-Fi Link support both iOS and Android device.

COMPATIBLE LIST

- TS160 Brushless ESC
- TS120 Brushless ESC (include a black aluminum edition)
- TS90 Brushless ESC
- 1S120 Brushless ESC

SPECIFICATION

- Input Voltage: 5-17V
- Input Current: 200mA
- Working Temp: 0-50°C / 32-122°F
- Storage Temp: -10 – 80°C / 14-176°F
- Dimension: 60.4x30x11mm
- Weight: 12g

APPLICATION FOR ESC

1. Download “Gforce Link” App from Apple’s App Store or Google Play and install the APP to your device.

2. Connect the ESC and Wi-Fi Module as following,



Scan to Download Gforce Link.



SmartPhone



3. Turn on the ESC first. The LED of Wi-Fi indicator will be blinking after 10 seconds. Please wait another 30 seconds. The LED of Wi-Fi indicator will remain on.

Connecting Wi-Fi Module with your iOS device

1. On your Smartphone, perform a search for available Wi-Fi networks. To do so, select Settings > Wi-Fi. The list of available Wi-Fi networks is displayed.
2. Select “GFORCEXXXX” and default password is “12341234”
3. Wait for your Smartphone to establish a connection with the Wi-Fi Module. It takes 10 seconds usually.
4. Launch “Gforce Link” Application. You are connected and ready for programing your ESC.

Connecting Wi-Fi Module with your Android device

1. On your Smartphone, perform a search for available Wi-Fi networks. To do so, select Settings > Wireless & Networking > Wi-Fi. The list of available Wi-Fi networks is displayed.
2. Select “GFORCEXXXX” and default password is “12341234”
3. Wait for your Smartphone to establish a connection with the Wi-Fi Module. It takes 10 seconds usually.
4. Launch “Gforce Link” Application. You are connected and ready for programing your ESC.

Change SSID and Password

1. You can change SSID of Wi-Fi Module in the “Gforce Link” App. To do so, select Upgrade > AP > SSID/Name > To change SSID.
2. You can change password of Wi-Fi Module in the “Gforce Link” App. To do so, select Upgrade > AP > Password > To change password.

RESTORE DEVICE

To restore the Wi-Fi Module to factory setting, press and hold the restore button for more than 5 seconds.



Products by
G-FORCE, Inc.
www.gforce-hobby.jp

Mare-kanda Bld.9F, 1-3-1, Kajicho, Chiyoda-ku,
Tokyo, 101-0044, JAPAN

Copyright © 2014 G FORCE, Inc. All Right Reserved.

Ver 1.00